

## STAR HK SL-8




### Insert the battery


Use the specified battery for your gun. 8.4V 1700mAh




#### Setting the magazine




#### Firing mode




## Hop-up adjustment



#### Butt Pad & Cheekpiece Adjustment







- .Do not aim or shoot a person or animal as the target.
- .Avoid pulling the trigger carelessly.
- .Always put the gun in a case or bag when you carrying it.
- .Always set the switch lever to the safety position.
- .Do not look into the gun muzzle.
- .Always wear eye protective gear.
- .Store the airsoft gun at the places out of reach by children.
- .Do not disassemble or modify the airsoft gun.

#### Optional accessories


G36KE real size Handguard



G36KE over size Handguard




G36 real size Handguard with Bipod



G36 Dual Sighting Handle



G36 Rail Mount Base



G36K Scope with Rail




Ag36 Grenade Launcher



Sound Suppressor



2000 Rds C-Mag



470 Rds Mag



140 Rds Mag



# DATA OF STAR SL-8 ELECTRIC GUN

MATERIAL: NYLON FIBER & ZINC ALLOY

**HOPUP SYSTEM: ADJUSTABLE** 

**LENGTH: 980-1030MM** 

WEIGHT:3400G

**MAGAZINE CAPACITY: 20 ROUNDS** 

**BULLET: 6MM BB BULLETS** 

**BATTERY: 8.4V 1700mAH** 

**MOTOR: HIGH TORQUE FLAT MOTOR** 

