



STAR MACHINENPISTOLE




Insert the battery


Use the specified battery for your gun.
8.4V 1700mAh




Setting the magazine



Firing mode



Hop-up adjustment



Folding Stock

